



- NOTES:
1. CAST STAINLESS STEEL ANCHOR SHACKLE AND THE CLEVIS END FOR THE SCREW JACK MUST BE FIT CHECKED ONCE BOTH ARE RECEIVED. IF INTERFERENCE EXISTS, DO NOT REWORK UNTIL ANALYSIS HAS BEEN PERFORMED AND APPROVAL HAS BEEN RECEIVED.
 2. MODIFICATIONS REQUIRED FOR MACHINE SCREW JACK:
 - A. REMOVE PROTECTIVE CAN FROM BASE
 - B. INSTALL CLEVIS END, CUT OFF SCREW LENGTH SUCH THAT SCREW IS FLUSH WITH BASE WHEN 1" OF SCREW PROTRUDES ABOVE JACK BODY
 - C. DRILL & TAP KNULED KNDB FOR SET SCREWS TO LOCK IN PLACE AT INPUT SHAFT KEYWAYS, INSTALL KNDB ON MACHINE SCREW JACK

D020280-02-D
PEPI RETROFIT ASSY
LIGD PROJECT
L JONES 6/05/02