

## CALIFORNIA INSTITUTE OF TECHNOLOGY PASADENA, CALIFORNIA 91125

## FACSIMILE COVER SHEET

LIGO FAX (818) 304-9834

TELEPHONE CONFIRMATION (818) 395-2966

TO

Marty Tellalian

**CBITSC** 

DATE

November 10, 1994

FAX NUMBER

OFFICE NUMBER

NUMBER OF PAGES (including this cover sheet): 1

FROM

Larry K. Jones

OFFICE NUMBER

(818) 395-2970

California Institute of Technology 102-33 Bridge Laboratory Pasadena, CA 91125

## Water break test:

Use distilled water (deionized is acceptable)

Set up two (small) demo surfaces (each with surface characteristics of that to be tested, as HRAP with oxide, etc.):

- · Clean one sample thoroughly, with Mirachem, acetone, and alcohol, in that order.
- · Smear oil on second sample and wipe clean.

Use an eyedropper to drop beads of water on each surface. Inspect each droplet, noting the angle droplet surface makes with the demo surface. If included angle is acute, surface is clean; if obtuse, surface is clean. Note: beads with obtuse angles should be prodded to overcome any possible water film contamination for confirmation; if in a clean surface, this will cause them to "flip" to an acute angle.

Once the examiner feels comfortable with the techniques, test the surfaces in question.