



EQUIPMENT LOCATIONS			
	LHO 2K	LHO 4K	LLO 4K
Box 1	2X8-XX	1X2-XX	1X2-XX
Box 2	2X8-XX	1X2-XX	1X2-XX
Box 3	2X8-XX	1X2-XX	1X2-XX
Box 4	2X2-XX	1X8-XX	1X8-XX
Box 5	2X6-XX	1X4-XX	1X4-XX
Box 6	2X2-XX	1X8-XX	1X8-XX
Box 7	2X1-XX	1X9-XX	1X9-XX
Box 8	2X8-XX	1X2-XX	1X2-XX
RF Splitter	2X8-XX	1X2-XX	1X2-XX
4116	2X6-20-7	1X4-20-7	1X4-20-7

FREQUENCY ASSIGNMENTS			
	LHO 2K	LHO 4K	LLO 4K
Frequency A	29.508 MHz	24.495 MHz	24.495 MHz
Frequency B	26.717 MHz	33.289 MHz	33.289 MHz
Frequency C	68.800 MHz	61.232 MHz	61.232 MHz

Note 1: Cable is Andrews 0.25 in. Superflex Heliax. Connectors are SMA right angle Andrews Part No. F1PSR

Note 2: Cable is RG405 coaxial. Connectors are SMA right angle PE4025

Note 3: Cable is shielded twisted pair. MOD CONT IN end connector is LEMO Part No. FFA.OS.302.CLAK62