

# Thermal Loading of Optical Components in Interferometric Systems


Carsten Janke

the Stanford gravitational wave group

LSC conference March 14-17, 2001

1


# Simplified Set-up



2

# Expected power absorption effects

- change in radius of curvature due to thermal expansion
  - decreasing mode coupling efficiency  $\kappa_{00}$
  - power drop in  $P_{\text{transmitted}}$
- slow thermal change of mirror surfaces




$$\kappa_{00} = f(\omega_e, \omega_{\text{inc}}, R_e, R_{\text{inc}})$$




# Power measurement $P_{\text{trans}}$ vs. $P_{\text{inc}}$

- slopes of fits within 19 %,
- 27 ppm mirror roll-off:  $\approx 0.5$  W




# $P_{\text{trans}}$ converted into a change $\Delta d$

- Slopes up to different absorptions



5




# Possible explanations

- changed impedance match conditions due to higher absorption
- change in coupling efficiency  $\kappa_{00}$  due to change in radius of curvature
- absorption of radiation by water vapor
- light from the  $\text{TEM}_{00}$  mode is scattered into higher order modes

# Light from the $\text{TEM}_{00}$ mode is scattered into higher order modes

- absorbed power leads to a dimple on mirror surface
- due to scatter light inside the cavity is propagating in higher order modes
- coupling efficiency degrades with  $1/(\text{modenumber}^2)$   $\kappa_{00} \rightarrow \kappa_{mn}$
- incident light is not longer transmitted but reflected



# Summary

- it is possible to increase (by ppm's) absorption loss of mirror coating by depositing a chrome layer
- the cavity was driven to sub linearity due to power absorption in the curved mirror
- sub linear behaviour is most likely up to the fact that at higher power levels light is scattered into higher order modes which leads to a significant decreased coupling efficiency



# Future work

- increase mode and impedance matching to reach critical power earlier
- test chrome coated mirrors
- also use untreated low loss mirrors
- determine intracavity loss with ring-down measurement
- monitor reflected power to observe locking mode
- change average power levels by chopping incident beam

9