Mechanical loss of optical coating at low temperature

ICRR Univ. of Tokyo, KEK^A,
Dept. of Phys. University of Tokyo^B, NAOJ^C, JAE^D

K. Yamamoto, S. Miyoki, T. Uchiyama, H. Ishizuka, M. Ohashi, K. Kuroda,

T. Tomaru^A, N. Sato^A, T. Suzuki^A, T. Haruyama^A, A. Yamamoto^A,

T. Shintomi^A, K. Numata^B, K. Waseda^C, K. Ito^D, K. Watanabe^D

Feb.7.2003
Aspen 2003
Gravitational Wave Advanced Detector Workshop
@Aspen, Colorado, U.S.A.

LIGO-G030225-00-Z

0. Abstract

In order to evaluate the thermal noise of LCGT

- (i) we measured the mechanical loss

 of the reflective coating of the mirror

 at low temperature.
- (ii) we measured the mechanical loss of the CaF₂, alternative material of the mirror, at low temperature.

Contents

- 1. Introduction
- 2. Outline of Experiment
- 3. Result
- 4. Discussion
- 5. Q-values of CaF₂
- 6. Summary

1. Introduction

LCGT: future Japanese project to construct
the interferometric gravitational wave detector

Thermal noise suppression in LCGT: cool mirror (20 K)

Thermal noise also depends on the mechanical loss.

Sapphire (material of mirror): sufficiently small loss (T. Uchiyama et al., Phys.Lett.A 261(1999)5.)

Loss of the reflective coating?

measurement of the loss of the coating at low temperature

2. Outline of Experiment

- (i) Sapphire disk with and without coating
- (iii) Estimation of coating loss from the measured Q-values

Advantage of this experiment

- (i) Thin disk: large effect of coating loss
- (ii) Resonant frequencies (>500Hz)

are near the observation band (about 100Hz).

2-1. Sapphire disk and coating

Sapphire disk: **f**100 mm t 0.5 mm and t 1 mm commercial polish (both sides)


Shinkosya (Japanese company)

Coating: IBS @ National Astronomical Observatory of Japan (K.Waseda) and Japan Aviation Electronics Industry, Ltd. (TAMA mirror coating by JAE.)

Ta₂O₅/SiO₂ (31 layers): typical material
Reflectivity is the same
as that of typical end mirror (>99.99%).


2-2. Support system

Nodal support system (K.Numata et al., Phys.Lett.A 276(2000)37.)




Our system: Copper (for cooling)

Nodal support system




2-3. Exciter and sensor

electrostatic actuator and electrostatic transducer




Exciter and sensor



2-4. Cooling

Vacuum tank in liquid He or N₂

at KEK(High Energy Accelerator Research Organization)



3.Result

3-1. Samples

```
measured sapphire disks
```

```
NAO coating: t 0.5, 1 mm disk, without annealing
```


JAE coating: t 1 mm disk, with and without annealing


no coating: t 0.5, 1 mm disk

measured modes: first and third mode

first mode third mode t 0.5 mm 520 Hz 1200 Hz t 1 mm 1100Hz 2500 Hz


K. Numata measured Q-values of fused silica disk at room temperature. (NAO coating)






3-2. Measured Q-values

JAE coating on t 1mm disk with annealing




Decay of resonant motion




3-3. Loss angle of coating

NAO coating on t 1mm disk without annealing



Temperature [K]

JAE coating on t 1mm disk with annealing



Temperature [K]

3-4. Summary of results

(i) Loss angle of coating is about $4*10^{-4}$.

This value is not so good.

Measurement of other groups at 300K: 6*10⁻⁵ -4*10⁻⁴

(ii) Loss angle of all samples in all cases are the same.

Loss of JAE coating is as large as that of NAO coating.

Loss angle of coating does not depend on temperature,

resonant frequency, thickness of sapphire disk.

Annealing does not affect loss of coating.

4. Discussion

- 4-1. Property of coating loss
 - (i) Loss angle is independent of temperature (4.2K-300K).

Thermal noise of coating loss is proportional to $T^{1/2}$.

ex.) (thermal noise at 20 K) = (thermal noise at 300 K) /4

advantage of cryogenic interferometer

(ii) Loss angle is independent of temperature (4.2K-300K).


Expectation: Coating loss becomes larger at low temperature

because loss of cool SiO₂ is large.

Coating loss is not dominated by intrinsic loss of SiO₂.

(iii) Loss angle is independent of resonant frequency and mode. → Structure damping model is valid. (iv) Loss angle is independent of thickness of disk. → Strain does not increase loss. (v) Annealing does not change the loss angle. Strain does not increase loss.

4-2. Thermal noise in LCGT



5.Q-values of CaF₂

5-1. Motivation

sapphire: material of mirror in LCGT

small thermal noise, but large heat absorption (20ppm/cm, about 1W)

Alternative material?

Material of future European project?

small heat absorption (2ppm/cm, about 0.1W)

Is thermal noise is small?

measurement of Q-values of CaF₂ at low temperature using same apparatus for coating loss

 \rightarrow CaF₂

5-2. Sample and experimental apparatus

 CaF_2 disk : $\mathbf{f}100$ mm t 3 mm


Both sides are polished.

Ouyou-kouken (Japanese company)

measured modes: first and third mode


first mode third mode t 3 mm 1870Hz 4300 Hz

Experimental apparatus is the same as that for coating loss.




Temperature [K]

5-4. Thermal noise of CaE in LCGT




6.Summary

- (1) Coating
 - (i) Measurement of mechanical loss of reflective coating at low temperature.
 - (ii) Coating loss is independent of temperature (4.2K-300K).
 - advantage of cryogenic interferometer
 - (iii) Coating loss is not a serious problem in LCGT.
 - (2) CaF₂
 - (i) Measurement shows that Q-values below 10K are 10⁷ at least.
 - (ii) Temperature of CaF₂ must be 5K in LCGT if it is used.




Temperature [K]

Measurement of other group



Q-values of CaF2



Thermal noise of CaF in LCGT

