

## **NOTE**

The sample source code provided for the ALD118 has the following default communications settings for RS232 communications with a PC serial port:

COM 1  
9600 Baud  
8 Data Bits  
No Parity  
1 Stop Bit

To utilize the serial port with RS232 communications requires the CA232 cable adapter and CCRJ12 cable. These items are included with the ALD118.

A copy of this source code and additional cabling information is available for free download from [www.masterclock.com](http://www.masterclock.com) or contact [support@masterclock.com](mailto:support@masterclock.com)