




L1:DMT-SNSH\_EFFECTIVE\_RANGE\_MPC.mean,m-trend




L1:DMT-SNSH\_EFFECTIVE\_RANGE\_MPC.mean,m-trend



L1:PSL-POWER\_SCALE\_OUT16




L1:DCS-CALIB\_STRAIN\_C01








L1 Displacement Sensivity, Jul 20 2017 06:43:42 UTC  
Input Power 25.8 [W],  $D_{\text{SenseMon}}(1.4/1.4, 10/10, 30/30 [M_{\text{sol}}]) = (98.18, 494, 1218) [\text{Mpc}]$






L1 Displacement Sensivity, Jul 20 2017 06:43:42 UTC  
Photon Calibration Excitation Frequency Zoom




created by produceofficialstrainads\_C02\_C01 on 24-Aug-2017, J. Kissel



L1 Displacement Sensivity, Jul 20 2017 06:43:42 UTC  
GDS C01 Calibration / Photon Calibration Residual Zoom




L1 PUM/UIM Actuation Strength Change





Delta = linfit ( @ 420 [s] ) - linfit ( @ 0 [s] )



t0 = Jul 20 2017 06:43:42 UTC




N Points: 6720; N Bins 26








L1 TST Actuation Strength Change





Delta = linfit ( @ 420 [s] ) - linfit ( @ 0 [s] )




t0 = Jul 20 2017 06:43:42 UTC




N Points: 6720; N Bins 26




L1 Optical Plant Change



t0 = Jul 20 2017 06:43:42 UTC



Delta = linfit ( @ 420 [s] ) - linfit ( @ 0 [s] )



N Points: 6720; N Bins 26

